



## EMC-60 Programming Reference

Wake-up the keypad by touching <WAKE>.

Select <PROGM> for program mode.

**Primary Phone Number:** Touch <1><ENTER>. Key-in the phone number, then touch <ENTER>.

**Secondary Phone Number:** Touch <2><ENTER>. Key-in the phone number, then touch <ENTER>.

**Location Announcement:** Touch <4><ENTER>. Record the location, cab number and that help is required, then touch <ENTER>.

Verify with <4><REPLAY>.

**Station Number:** Touch <5><ENTER>. Key-in the cab # and <ENTER>.

**Language:** Touch <10><ENTER> and select <0> English, <1> French, <4> Spanish then touch <ENTER>.

**Talk Time:** Touch <15><ENTER>. Key-in the time (3 to 30 minutes), then touch <ENTER>.

**PLM Test:** Touch <24><ENTER>. Key-in the time (up to 100 seconds), then touch <ENTER>.

**Remote call:** Touch <19><ENTER>. Key-in the phone number, then touch <ENTER>. Touch <20><ENTER><2><ENTER>.

Touch <EXIT> to exit programming mode.

Check **Alarm Status:** Touch <WAKE> then <ALARM STATUS>.

**Line Test:** Touch <WAKE> then <LINE TEST> and dial normally.

Touch <EXIT> to end the call.

**Customer Care:** Call 1-844-EMERCOM (1-844-363-7266)